

Installing the Compression Brick Driver

If you swapped Windows disks, recovery disks, or Compression Bricks, you must replace the incorrect (Windows generic) driver with the correct driver. Use the following steps to update the driver:

1. Right-click on **My Computer** and select **Properties**.
2. Browse to **Hardware > Device Manager > Generic 1394 Desktop Camera**.
3. Right click on **Generic 1394 Desktop Camera** and select **Update Driver**.
4. In the Found New Hardware Wizard (or similar dialog) select **No Not this Time**.
5. Click **Next**.
6. Select **Install from a list or specified location (Advanced)**.
7. Click **Next**.
8. Select **Don't search, I will choose the driver to install**.
9. Click **Next**.
10. If available, select **PGR Compressor**, click **Next**, and skip to step 15; Otherwise select **Have Disk**.
11. In the Install from Disk dialog select **Browse to Drive** and go to
C:\iMove\Point_Grey\ladybug.inf.
12. Click **Open**.
13. Back in the Install from Disk dialog click **OK**.
14. Select **PGR Compressor** and click **Next**.
15. A progress indicator displays for a moment. In the Completing the Found New Hardware Wizard dialog click **Finish**.
16. Close the Found new Hardware bubble that appears and disconnect the Firewire cable.
17. Listen for the two-tone beep and wait 10 seconds before re-connecting the Firewire cable to the Toughbook.
18. Wait 10 seconds before starting GeoCapture.